


























Problems on motors and optic sensor

1_g	PAN is loosing the position	Check/replace motor 23	Tav P12-1 1200DVP	
		Replace U20	TROUBLE 04B434	
		Ceck R91=~1 ohm	TROUBLE 04B434	
		Ceck R101=~1 ohm	TROUBLE 04B434	
2_g	TILT is loosing the position	Check/replace motor 22	Tav P12-1 1200DVP	
		Replace U21	TROUBLE 04B434	
		Ceck R102=~1 ohm	TROUBLE 04B434	
		Ceck R96=~1 ohm	TROUBLE 04B434	
3_g	The shutter/strobe is loosing posit.	Check/replace motor 28-29	Tav P12-2 1200DVP	
		Replace U14	TROUBLE 04B434	
		Ceck R37= ~1 R43=~1	TROUBLE 04B434	
		Check position 4 ON of S1	TROUBLE 04B434	
4_g	The GOBOS is loosing the position	Check/replace motor 16	Tav P12-2 1200DVP	
		Replace U13	TROUBLE 04B434	
		Ceck R42= 1 R32=1	TROUBLE 04B434	
5_g	The GOBOSdoesn't make the reset	Clean the border of the wheel 8	Tav P12-2 1200DVP	
		Check sensor ref 7	Tav P12-2 1200DVP	
6_g	The color wheel is loosing position	Check/replace motor 30	Tav P12-2 1200DVP	
		Replace U18	TROUBLE 04B434	
		check R80= ~1 ohm R86=~1ohm	TROUBLE 04B434	
7_g	The color doesn't make the reset	Clean the border of the wheel 27	Tav P12-2 1200DVP	
		Check sensor ref 26	Tav P12-2 1200DVP	
8_g	The rotat gobos is loosing position	Check/replace motor 6	Tav P12-2 1200DVP	
		Replace U17	TROUBLE 04B434	
		Ceck R85= ~1 R75=~1	TROUBLE 04B434	
9_g	The rotat gobos doesn't make reset	Check sensor ref 7	Tav P12-2 1200DVP	
10_g	The effects wheel is loosing position	Check/replace motor 12	Tav P12-2 1200DVP	
		Replace U23	TROUBLE 04B434	
		check R117= ~1 ohm R107=~1ohm	TROUBLE 04B434	
11_g	The effetc doesn't make the reset	Clean the border of the wheel 5	Tav P12-2 1200DVP	
		Check sensor ref 9	Tav P12-2 1200DVP	
12_g	The rotat prism is loosing position	Check/replace motor 2	Tav P12-2 1200DVP	
		Replace U24	TROUBLE 04B434	
		check R112= ~1 ohm R118=~1ohm	TROUBLE 04B434	